

**NOTES:**

1. CHARGE EXPANSION TANK TO 2 PSIG BELOW SYSTEM OPERATING PRESSURE AT THE POINT OF CONNECTION TO THE SYSTEM AND TAG TANK WITH AIR PRESSURE SETTING. CHARGE EXPANSION TANK AIR PRESSURE BEFORE CONNECTING TO HYDRONIC SYSTEM.
2. EXPANSION TANK CAN BE FLOOR MOUNTED OR HUNG ABOVE.
3. PRESSURE SWITCH SHALL BE SET TO 15 PSI ABOVE SYSTEM SUCTION PRESSURE.
4. ALL GLYCOL TO BE INHIBITED PROPYLENE GLYCOL NOT LESS THAN 33.33% BY VOLUME (CAN BE MORE IF NEEDED).
5. PRESSURE REGULATOR CAN BE IN TANK CONTROL BUT NOT A PRESSURE SWITCH DIRECT TO SYSTEM.
6. PIPE ALL AIR VENTS SHOWN ON THIS DRAWING BACK TO GLYCOL FEED TANK.

