



NOTES:

1. WHEN CONDENSATE PUMP IS INSTALLED IN A PIT, MOUNT CONTROL CABINET ON WALL OUTSIDE OF PIT IN A LOCATION WITH A CLEAR, UNOBSTRUCTED VIEW OF THE PIT. SEE PLANS FOR LOCATION.
2. IF CONDENSATE PUMP IS LOCATED IN A PIT OR VAULT, PROVIDE A HIGH WATER LEVEL FLOAT ALARM THAT IS CONNECTED TO THE BAS FOR EMERGENCY NOTIFICATION OF MECHANICAL SERVICES.
3. REFER TO SPECIFICATIONS FOR VALVES, STRAINERS AND ACCESSORY TYPES.
4. PROVIDE ISOLATION VALVE ON SUCTION SIDE OF EACH PUMP.

BAS: BUILDING AUTOMATION SYSTEM
VFD: VARIABLE FREQUENCY DRIVE